D104204X012

July 2017

FM Hazardous Area Approvals Fisher™ FIELDVUE™ DVC6200 Series Digital Valve Controllers



Hazardous Area Approvals and Special Instructions for "Safe Use" and Installations in Hazardous Locations

Certain nameplates may carry more than one approval, and each approval may have unique installation/wiring requirements and/or conditions of "safe use". These special instructions for "safe use" are in addition to, and may override, the standard installation procedures. Special instructions are listed by approval type.

Note

This information supplements the nameplate markings affixed to the product and the DVC6200 Series quick start guide (<u>D103556X012</u>), available from your Emerson sales office or Local Business Partner, or at <u>Fisher.com</u>.

Always refer to the nameplate itself to identify the appropriate certification.

A WARNING

Failure to follow these conditions of "safe use" could result in personal injury or property damage from fire or explosion and area re-classification.

Explosion-proof, Dust-Ignition proof, Non-Incendive, Suitable for Use DVC6200 and DVC6205 Series (HART HW1 & HW2, SIS, FOUNDATION FIEldbus, PROFIBUS)

XP: Class I, Division 1, Groups B,C,D DIP: Class II, III, Division 1, Groups E,F,G NI: Class I, Division 2, Groups A,B,C,D S: Class II, III, Division 2, Groups F,G Class I Zone 1 AEx d IIC Class I Zone 2 Ex nC IIC T5 Ta = 80°C, T6 Ta = 75°C Type 4X, IP66





DVC6215 Remote Mount

XP: Class I, Division 1, Groups A,B,C,D DIP: Class II, III, Division 1, Groups E,F,G NI: Class I, Division 2, Groups A,B,C,D S: Class II, III, Division 2, Groups F,G Class I Zone 1 AEx d IIC Class I Zone 2 Ex nA IIC
Ta = 125°C, T5 Ta = 90°C, T6 Ta = 75°C Type 4X, IP66

Intrinsically Safe

IS Class I, II, III, Division 1, Groups A,B,C,D,E,F,G Class I Zone 0 AEx ia IIC

Type 4X, IP66

Intrinsically safe when connected per control drawing GE42819, as shown in the following figures


DVC6200 HW2 and DVC6200 SISfigure 1 and 6DVC6205, DVC6205 SIS, and DVC6215 Remote Mountfigure 2 and 6DVC6200f and DVC6200pfigure 3 and 6DVC6205f, DVC6205p, and DVC6215 Remote Mountfigure 4 and 6DVC6200 HW1figure 5 and 6

Special Conditions of Safe Use

- When product is used with natural gas as the pneumatic medium, the maximum working pressure of the natural gas supply shall be limited to 10 bar (145 psi).
- When product is used with natural gas as the pneumatic medium the product shall not be permitted in a Class I, Division 2, Group A, B, C, D location without the proper venting installation per the manufacturer's instruction manual.
- The apparatus enclosure contains aluminum and is considered to constitute a potential risk of ignition by impact or friction. Care must be taken into account during installation and use to prevent impact or friction.
- Part of the enclosure is constructed from plastic. To prevent the risk of electrostatic sparking the plastic surface should only be cleaned with a damp cloth.

D104204X012 July 2017

Figure 1. FM Loop Schematics—FIELDVUE DVC6200 HW2 and DVC6200 SIS




** Li = 0.15 mH when the AUX Terminals are not used

		WITH	WITHOUT
		I/O PACKAGE	I/O PACKAGE
	T CODE	T (amb)	T (amb)
	T5	≤ 80°C	≤ 80°C
	Т6	≤ 61°C	≤ 74°C

GE42819 Sheet 11, Rev. B


1 SEE NOTES IN FIGURE 6




1> SEE NOTES IN FIGURE 6

D104204X012 July 2017

Figure 3. FM Loop Schematics—FIELDVUE DVC6200f and DVC6200p




1 SEE NOTES IN FIGURE 6



1 SEE NOTES IN FIGURE 6


July 2017 D104204X012

Figure 4. FM Loop Schematics—FIELDVUE DVC6205f, DVC6205p, and DVC6215



1> SEE NOTES IN FIGURE 6


ENTITY FIELDBUS LOOP



1 SEE NOTES IN FIGURE 6

D104204X012 July 2017

Figure 5. FM Loop Schematic—FIELDVUE DVC6200 HW1



1> SEE NOTES IN FIGURE 6

Figure 6. Notes for FM Loop Schematics

☐ THE ENTITY CONCEPT ALLOWS INTERCONNECTION OF INTRINSICALLY SAFE APPARATUS TO ASSOCIATED APPARATUS NOT SPECIFICALLY EXAMINED IN SUCH COMBINATION. THE CRITERIA FOR INTERCONNECTION IS THAT THE VOLTAGE (Vmax OR Ui), THE CURRENT (Imax OR Ii), AND THE POWER (Pmax or Pi) OF THE INTRINSICALLY SAFE APPARATUS MUST BE EQUAL TO OR GREATER THAN THE VOLTAGE (Voc OR Uo), AND THE CURRENT (Isc OR Io), AND THE POWER(Po) DEFINED BY THE ASSOCIATED APPARATUS. IN ADDITION, THE SUM OF THE MAX UNPROTECTED CAPACITANCE (Ci) AND MAX UNPROTECTED INDUCTANCE (Li), INCLUDING THE INTERCONNECTING CABLING CAPACITANCE (Ccable) AND CABLING INDUCTANCE (Lcable) MUST BE LESS THAN THE ALLOWABLE CAPACITANCE (Ca) AND INDUCTANCE (La) DEFINED BY THE ASSOCIATED APPARATUS. IF THE ABOVE CRITERIA IS MET, THEN THE COMBINATION MAY BE CONNECTED.

Vmax or Ui ≥ Voc or Uo Imax or Ii ≥ Isc or Io Pmax or Pi ≥ Po Ci + Ccable ≤ Ca Li + Lcable ≤ La

② THE FISCO CONCEPT ALLOWS INTERCONNECTION OF INTRINSICALLY SAFE APPARATUS TO ASSOCIATED APPARATUS NOT SPECIFICALLY EXAMINED IN SUCH COMBINATION. THE CRITERIA FOR THE INTERCONNECTION IS THAT THE VOLTAGE (Vmax OR Ui), CURRENT (Imax OR Ii), AND POWER (Pmax or Pi), WHICH AN INTRINSICALLY SAFE APPARATUS CAN RECEIVE AND REMAIN INTRINSICALLY SAFE, CONSIDERING FAULTS, MUST BE EQUAL TO OR GREATER THAN THE VOLTAGE (Voc OR Uo), CURRENT (Isc OR Io), AND POWER (Po) LEVELS WHICH CAN BE DELIVERED BY THE ASSOCIATED APPARATUS, CONSIDERING FAULTS AND APPLICABLE FACTORS. IN ADDITION THE MAXIMUM UNPROTECTED CAPACITANCE (Ci) AND INDUCTANCE (Li) OF EACH APPARATUS (OTHER THAN THE TERMINATION) CONNECTED TO THE FIELDBUS MUST BE LESS THAN OR EQUAL TO 5 nF AND 10 uH RESPECTIVELY.

IN EACH SEGMENT ONLY ONE ACTIVE DEVICE, NORMALLY THE ASSOCIATED APPARATUS, IS ALLOWED TO PROVIDE THE NECESSARY ENERGY FOR THE FIELDBUS SYSTEM. THE VOLTAGE (Uo OR Voc OR Vt) OF THE ASSOCIATED APPARATUS HAS TO BE LIMITED TO THE RANGE OF 9 V TO 17.5 VDC. ALL OTHER EQUIPMENT CONNECTED TO THE BUS CABLE HAS TO BE PASSIVE, MEANING THAT THEY ARE NOT ALLOWED TO PROVIDE ENERGY TO THE SYSTEM, EXCEPT FOR A LEAKAGE CURRENT OF 50 uA FOR EACH CONNECTED DEVICE. SEPARATELY POWERED EQUIPMENT NEEDS A GALVANIC ISOLATION TO ASSURE THAT THE INTRINSICALLY SAFE FIELDBUS CIRCUIT REMAINS PASSIVE.

CONTINUED ON NEXT PAGE...

July 2017 D104204X012

Figure 6. Notes for FM Loop Schematics

2 CONTINUED

THE CABLE USED TO CONNECT THE DEVICES NEEDS TO HAVE THE PARAMETERS IN THE FOLLOWING RANGE:

LOOP RESISTANCE R': 15 TO 150 ohms/km INDUCTANCE PER UNIT LENGTH L: 0.4 TO 1 mH/km CAPACITANCE PER UNIT LENGTH C': 80 TO 200 nF/km

C' = C' LINE/LINE + 0.5' LINE/SCREEN, IF BOTH LINES ARE FLOATING OR

C' = C' LINE/LINE + C' LINE/SCREEN, IF THE SCREEN IS CONNECTED TO ONE LINE.

LENGTH OF SPLICE: <1 m (T-BOX MUST ONLY CONTAIN TERMINAL CONNECTIONS WITH NO ENERGY STORAGE CAPABILITY)

LENGTH OF SPUR CABLE: < 30 M LENGTH OF TRUNK CABLE: < 1 km

AT EACH END OF THE TRUNK CABLE AN APPROVED INFALLIBLE TERMINATION WITH THE FOLLOWING PARAMETERS IS SUITABLE: R = 90 TO 100 ohms AND C = 0 TO 2.2 uF

NOTE, A BUILT-IN TERMINATOR IS INCLUDED IN THE FIELD SIDE AND A SELECTABLE TERMINATOR IS AVAILABLE ON THE HOST SIDE.

THE NUMBER OF PASSIVE DEVICES CONNECTED TO THE BUS SEGMENT IS NOT LIMITED IN THE FISCO CONCEPT FOR INTRINSICALLY SAFE REASONS. IF THE ABOVE RULES ARE RESPECTED, UP TO A TOTAL LENGTH OF 1000 m (SUM OF THE LENGTH OF THE TRUNK CABLE AND ALL SPUR CABLES), THE INDUCTANCE AND CAPACITANCE OF THE CABLE WILL NOT IMPAIR THE INTRINSIC SAFETY OF THE INSTALLATION.

- 3 INSTALLATION MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC) AND ANSI/ISA RP12.6.01.
- 4 MAXIMUM SAFE AREA VOLTAGE SHOULD NOT EXCEED 250 Vrms.
- **IDENTIFY AND SET OF THE PROOF.**IN RESISTANCE BETWEEN INTRINSICALLY SAFE GROUND AND EARTH GROUND MUST BE LESS THAN ONE OHM
- **IDENTIFY AND SET OF THE BARRIER MANUFACTURER'S INSTRUCTIONS.**
- ☐ IF HAND-HELD COMMUNICATOR OR MULTIPLEXER IS USED, IT MUST BE FM APPROVED WITH ENTITY PARAMETERS AND INSTALLED PER THE MANUFACTURER'S CONTROL DRAWINGS.

▲ WARNING

THE APPARATUS ENCLOSURE CONTAINS ALUMINUM AND IS CONSIDERED TO CONSTITUTE A POTENTIAL RISK OF IGNITION BY IMPACT AND FRICTION. AVOID IMPACT AND FRICTION DURING INSTALLATION AND USE TO PREVENT RISK OF IGNITION.

GE42819, Sheet 8, Rev. F

Neither Emerson, Emerson Automation Solutions, nor any of their affiliated entities assumes responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end user.

Fisher and FIELDVUE are marks owned by one of the companies in the Emerson Automation Solutions business unit of Emerson Electric Co. Emerson Automation Solutions, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. All other marks are the property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson Automation Solutions Marshalltown, Iowa 50158 USA Sorocaba, 18087 Brazil Cernay, 68700 France Dubai, United Arab Emirates Singapore 128461 Singapore

www.Fisher.com

